

Nitrogen Generator Room Entry Procedures (Applicable for Ships having N₂ Generator Plant)	Poster 018B
---	--

- The ventilation fan must be turned on at least 20 minutes prior to entry in this room.
- The ventilation fan must be kept running at all time while Nitrogen Plant is in operation.
- Prior to entry of personnel, the atmosphere in this space must be tested for Oxygen content as per below:
 - ◆ By checking the reading of fixed oxygen detector, if fitted.
 - ◆ By using a portable Oxygen detector, if the fixed detector is not fitted.
- To be considered safe for entry, the atmosphere in these spaces must be verified to have:
 - ◆ 20.9% Oxygen.
- A personal Oxygen monitor & alarm must be worn by at all times by personnel entering this room.
- A radio must be worn at all times by at least one of the personnel entering the Nitrogen Generator Room.
- The duty officer must be notified by radio on each occasion personnel enter these spaces and every 15 minutes thereafter.
- The space must be evacuated immediately in case if low oxygen alarm of personal gas detector sounds any time.

**This notice must be displayed at the entrance of
Nitrogen Generator Room**